

# Purasol™ LS2 Solvent Purifier

*Maximizes metal removal efficiencies over a broad range of photochemical solvents*

Building upon the success of our Purasol™ SP/SN solvent purifiers, our Purasol LS2 solvent purifier maximizes metal removal efficiencies over a broad range of photochemical solvents and polymer solutions to enable customers to control contamination and achieve maximum cleanliness. Using a uniquely tailored PTFE membrane, the cleaner substrate enables shorter filter conditioning time, and the versatile purifier can efficiently remove metal contaminants from a variety of raw materials used in photochemical manufacturing.



*Available in multiple formats and sizes to meet your application needs*

## APPLICATIONS

- Photolithography solvents
- Raw materials and intermediates (resin, polymer solutions, etc.) used in photochemical manufacturing

## FEATURES & BENEFITS


Novel functionalization	Greater than 99% metal removal for certain chemicals
Improved cleanliness	Cleaner substrate enables shorter filter conditioning time
Optimized morphology	Longer filter lifetime
Broader application	Effective in most commonly used photochemical solvents

## SPECIFICATIONS


<b>Materials</b>	Membrane	Polytetrafluoroethylene (PTFE)
	Supports, core sleeve, shell	High-density polyethylene (HDPE)
	O-ring (cartridges)	E-FKM
<b>Surface area (X-section)</b>	Cartridges	10" 1.1 m <sup>2</sup> (11.8 ft <sup>2</sup> )
		20" 2.2 m <sup>2</sup> (23.7 ft <sup>2</sup> )
	Disposable	0.18 m <sup>2</sup> (1.9 ft <sup>2</sup> )
<b>Fitting type</b>	Disposable	1/4" compression fitting
<b>Operating conditions</b>	Maximum forward differential pressure	0.24 MPa (2.4 bar, 35 psi) @ 25°C (77°F)
	Maximum reverse differential pressure	0.24 MPa (2.4 bar, 35 psi) @ 25°C (77°F)
	Maximum operating temperature	60°C (140°F)
<b>Flow conditions</b>	Initial flow rate @19.6 kPa (10" and 20") @58.8 kPa (Disposable)	10": 2.5 (L/min) ≤ PLTG01 ≤7 (L/min)
		20": 5.2 (L/min) ≤ PLTG02 ≤15 (L/min)
		Disposable: 1.7 (L/min) ≤ PLTG0S ≤3.6 (L/min)

## PERFORMANCE DATA


Typical Purasol LS2 10" Cartridge Solvent Purifier Flow Performance



Typical Purasol LS2 20" Cartridge Solvent Purifier Flow Performance




Typical Purasol LS2 Disposable Solvent Purifier Flow Performance



## DIMENSIONS


### Purasol Cartridge Purifiers – Code 0 (70 mm width)

#### Without Chemlock® Key



Length	A	B
10"	262.3 mm (10.33")	245.0 mm (9.65")
20"	506.5 mm (19.94")	489.2 mm (19.26")

### Purasol Disposable Purifier



## ORDERING INFORMATION

PART NUMBER	FORM FACTOR	LENGTH
PLTG01P2T01	Cartridge	10"
PLTG02P2T01	Cartridge	20"

## ORDERING INFORMATION

PART NUMBER	FORM FACTOR	LENGTH
PLTG0S1S121	Disposable	4.5"

### FOR MORE INFORMATION

Please call your Regional Customer Service Center today to learn what Entegris can do for you. Visit [entegris.com](https://www.entegris.com) and select the [Contact Us](#) link to find the customer service center nearest you.

### TERMS AND CONDITIONS OF SALE

All purchases are subject to Entegris' Terms and Conditions of Sale. To view and print this information, visit [entegris.com](https://www.entegris.com) and select the [Terms & Conditions](#) link in the footer.



Corporate Headquarters  
129 Concord  
Billerica, MA 01821  
USA

Customer Service  
Tel +1 952 556 4181  
Fax +1 952 556 8022  
Toll Free 800 394 4083

Entegris®, the Entegris Rings Design®, and other product names are trademarks of Entegris, Inc. as listed on [entegris.com/trademarks](https://www.entegris.com/trademarks). All third-party product names, logos, and company names are trademarks or registered trademarks of their respective owners. Use of them does not imply any affiliation, sponsorship, or endorsement by the trademark owner.

©2023 Entegris, Inc. | All rights reserved. | Printed in the USA | 4442-12778DSA-1223